

P203 - FFP2 Valved Dolomite Respirator (Pk10)

Collection: Disposable Mask FFP2

Range: Disposable Masks

Materials: PP, PU Foam

Inner Pack: 10

Outer Carton: 24

Product information

Comfortable cup shaped respirator with an exhalation valve for lighter breathing resistance. Adjustable nose clip for optimized fit. DOLOMITE optional clogging test.

Disposable Mask FFP2

Disposable mask FFP2 level, protects against solid and liquid particles of average toxicity. Minimal % of filtration 94%. Protects up to 10 times the TLV (Assigned Protection Factor for FFP2 masks). Examples of applications: Sanding of soft wood, composite materials, rust, putty, plaster, plastics /cutting, deburring, grinding, drilling of metal. Our Biztex brand ensures exceptional quality and performance across our full range of disposable masks.

Disposable Masks

Our Biztex® brand ensures exceptional quality and performance across our full range of disposable masks. The extensive Biztex® range offers a high level of protection and quality safeguarding the wearer against many workplace risks including liquid chemicals, static electricity, dry particles and radioactive contamination. The complete Biztex® range includes disposable masks and limited-life garments.

Standards

EN 149:2001 +A1:2009 FFP2 (NR D)



Features

- Ultrasonic welded head straps
- Adjustable nose bar for improved fit and reduced fogging of glasses
- High performance exhalation valve to reduce heat and provide comfort when used in hot and humid conditions
- Foam padding around the nose bridge for additional comfort
- Comfortable cup style respirator
- Dolomite optional clogging test (D) to provide more comfortable breathing and longer lasting filtration performance
- Retail box which aids presentation for retail sales
- CE certified
- UKCA marked
- CE-CAT III



PRODUCT SPECIFICATION & TECHNICAL DATASHEET

P203 - FFP2 Valved Dolomite Respirator (Pk10)

Commodity Code: 6307909311

Test House

BSI Group The Netherlands B.V. (Notified Body No.: NB: 2797)

John M. Keynesplein 9

, The Netherlands

Cert No: CE 783116

BSI Assurance UK Ltd (Notified Body No.: AB: 0086)

The British Standards Institution

MK5 8PP, United Kingdom

Cert No: UKCA 783117

Carton Dimensions/Weight

Item	Colour	Len	Wid	Hgt	Weight(Kg)	Cubic(m ³)	EAN13	GTIN/DUN14
P203WHR	White	65.0	44.0	36.0	0.2010	0.1030	5036108260133	25036108749526